

Digital HeatFX Miscellaneous Transfer Application Guide



Nylon

240°F

15 Seconds

Low Pressure



Neoprene

240°F

20 Seconds

Low Pressure



Canvas

260°F

30 Seconds

Medium Pressure



Polypropylene

220°F

30 Seconds

High Pressure

1. Perform your marry step according to EZ Peel paper instructions.
2. Arrange substrate on heat press and pre-press for 5-10 seconds to remove any wrinkles and/or moisture.
3. Lay heat transfer onto the substrate, cover with parchment/finishing sheet and press based upon the above parameters.
4. Carefully remove substrate from heat press and allow to completely cool before removing the A paper from the substrate.
5. To ensure matte finish and washability, repress with parchment/finishing sheet for 20-30 seconds.

**Pressing parameters are based upon internal testing using the Hotronix Fusion heat press. Your environment may require different times or temperatures. Any questions can be relayed to ColDesi support at support.coldesi.com/open-a-ticket.*

Updated 5/2019