


# Changing the GEMFix blades:

## Not correct

Blade-set must not have space between them.

## Not correct

Blade-set must not overlap one another.




## Correct

Blade-set should be like mirror images, forming a pyramid.

Blade length is best when you keep two 'blade-snaps' together.

Blade height from blade-holder is 3/4" - 7/8". Allow for a small pyramid of **air-space** at the base of the blade-set, see the diagram.

Position blade-set between blade-holder screws.



TIP: place the blades in the right position on your work-table, place a single piece of tape to hold them together on the front face of the blades. This helps a lot.

Suggestion: Check the blade height and proper blade spacing between jobs. Most blade issues stem from loosening up while in use. With experience you will know what a properly installed blade-set should look like.

\*\*\*\* DO NOT INSTALL BLADES WITH A FINISHED HEIGHT OF OVER 7/8\"/>